


STEVAL-IPT002V1 Application PCB Schematic



PRES config (JP17)
Please connect the 2 jumpers as follows:

PRES conf and SW kind	J1 pins	J2 pins
-PRES (SW N.C.)	1 - 5	2 - 3
+PRES (SW N.O.)	2 - 5	1 - 4
No Switch		Pin 2 of JP17 to J8

N.C. or N.O. switch is included in the Smartcard connector. Please select JP17 as specified in the PRES configuration.

Title	ST8024 Evaluation Board
Size	Document Number
Rev	1
Date	Wednesday, June 22, 2005
Sheet	1 of 1

A111898

